

2D Hinge Adjustment Instructions

.....

Can't find what you're looking for?
Give us a call on **0191 410 6631**


 BOWATER
DOORS



Tools Required:

- 4mm Allen Key
- PH2 screwdriver

Fig. A

**Horizontal Adjustment:**

Loosen screws **1** and **2** by three turns.


Tighten or loosen Allen Screw **3** with a **4 mm Allen Key**.

Tighten screws **1** and **2**.

Height Adjustment:

Turn Allen Screw **B** with a **4mm Allen Key** as shown in **Figure A**. Adjustment: **-2/+6mm**.

Fig. X



Insert caps and cover as shown in **Figure X**.

For more information please
contact our team on
0191 410 6631
or alternatively email
bowaterdoors@birtleygroup.co.uk